



## PROGRAMMING INSTRUCTIONS FOR INFRARED DOOR OPENER IR-2

### Functionality:

This infrared transmitter is provided with 2 different channels, each one is able to have either a different code or even the same. In case of programming just one code, it is better doing it in both channels to avoid activating by accident the channel which is not programmed.

It is suitable for duplicating and reproducing different formats of codes, used for the control of different vehicles.

The equipment is provided with a jumper (JP1) for the programming.

### Codes duplication:

To proceed to charge codes: do it in the following way:

1. Open the door opener lid.
2. Insert the jumper in the metallic terminals.
3. Keep pressing the button in the channel to be saved.
4. Light up with the original door opener the LED LD2 (just 5 cm away). Press more than once the original door opener, if it is needed till the LD1 starts to flicker. As it flickers the code would have been charged in this channel. If needed, repeat the same steps with the other channel.
5. Once the codes are charged, remove JP1 (insert it on one of the metallic terminals, in case reprogrammed is needed again).
6. Once executed these operations the equipment is ready for working, then close the door opener.